


DRUM REAR BEARING PLATE REPLACEMENT

Step 1 : REMOVAL OF EXISTING RIVETS
to remove failed shaft bearing plate



Step 2 : FITTING OF NEW BEARING PLATE
using new nuts and bolts.

